Installation Instructions for SGF-DA20B

The Swift Green SGF-DA20B is compatible with the following obsolete or alternate filter part numbers:

46-9101	DA-97-08006A	DA29-00020A	DA2900020B	HAF-CINEXP
4609101000	DA-97-08006A-	DA29-00020B	DA97-08006A-E	B HAFCIN
469101	В	DA2900019A	HAF-CIN	WF294
9101	DA-97-08006B	DA2900020A	HAF-CIN-EXP	
	DA29-00019A			

How To Install The Swift Green SGF-DA20B Filter:



Shut off the main water supply valve to the refrigerator Remove old cartridge by grasping firmly and twisting counterclockwise 1/4 turn Push new filter into the filter receiver and turn 1/4 turn clockwise until it locks Turn on the main water supply valve to the refrigerator Flush the refrigerator water system after replacing the water filter cartridge. Sputtering may occur until air is purged from water line and filter Reset water filter status display - replace filter every 6 months

Frequently Asked Questions

1. Is it easy to change one of these filters?

Yes. All of our filters can be changed by the average homeowner. You can always contact us for help if you have trouble.

2. Do these filters have an expiration date?

No. All of the filters we manufacture can sit on your shelf until you need them. We

recommend a cool, dark, dry location.

3. How do I know if my fridge has a built-in filter?

Fridges with built-in water filters are usually side by side models with built-in ice and water dispensers. If you have a fridge like this then you should look for the filter in one of three places.

- 1 Inside the refrigerator compartment hanging down from the top of the fridge. Look for cylinder shaped <u>plastic</u> or <u>metal</u> canisters.
- 2 Inside the refrigerator compartment, some filters <u>slide out</u> or <u>drop down</u> from the ceiling of the fridge.
- 3 Located in the grille at the bottom front of the refrigerator.

4. How do I reset my filter change indicator light?

If your refrigerator has an indicator that tells you when to change the filter, it needs to be reset when you replace the filter. Each manufacturer has different instructions for resetting the indicator.

- 1 Amana® press and hold the dispenser lock and auto light buttons on the dispenser (at the same time) for 4 seconds until the filter status indicator begins to flash, and then release the buttons. On some Amana fridges you need to press the dispenser lock and water buttons for 4 seconds until the filter status indicator begins to flash, and then release the buttons.
- 2 **Frigidaire** Press and hold the **reset** button on the dispenser until the green light flashes (up to 15 seconds).
- **3 GE and Hotpoint (®** press and hold the **reset water filter** button on the dispenser for 3 seconds.
- 4 Maytag® and Jenn-Air® press and hold the lock and light buttons (lock and water on newer fridges) on the dispenser for about 4 seconds, until the indicator light blinks.
- 5 Whirlpool® and Kitchen Aid® press the light switch 5 times within 10 seconds. If the fridge has a filter button, press and hold it for 5-10 seconds.
- 6 Samsung[®] press the ice type and child lock buttons simultaneously for 3 seconds.

Note: Hold the buttons for only 3 seconds. If you press these 2 buttons simultaneously for 5 seconds, the reset function ceases. Release the buttons and repeat the same step one more time. The water filter indicator light should turn green.

- 7 **LG®** press and hold the **reset** button for 3 seconds.
- 8 **Kenmore** Kenmore refrigerators are made by a number of different manufacturers, so please refer to our <u>Kenmore</u> <u>Section</u> to see which manufacturer made your refrigerator, then follow the directions listed above.

5. Do I need to lubricate the gaskets on my filter and receiver?

No, our filters have USDA food grade silicone lubricant applied from the factory.

6. Do you make house calls?

Unfortunately we are unable to make house calls - but trust us, SWIFT filters are easy to install. If you have difficulty installing one of our filters we can help. Call us at **888-223-6762 x102** between the hours of 8 am and 5 pm, Mon-Fri. PST or send us an <u>e-mail</u> at <u>cs@swiftgreenfilters.com</u>

7. Do you carry the colored plastic or metal end cap that covers the filter in my grill?

The cap you are referring to covers the end of the filter located in the base grill of some Whirlpool®, Kitchen Aid®, and Kenmore® refrigerators. The cap is not permanently connected to the filter so you don't need to buy a new one. When you remove the old filter, simply pull the cap off and put it on the new filter.

8. Atrazine, Methylbenzene, Lindale...... what are they, and why shouldn't I be drinking them?

Atrazine is a white, crystalline solid organic compound. It is a widely used herbicide for control of broadleaf and grassy weeds. Lindane is a white crystalline organic solid used primarily for treating wood-inhabiting beetles and seeds. It is also used as a dip for fleas & lice on pets and livestock, for soil treatment, on the foliage of fruit and nut trees, vegetables, timber, and ornamentals and for wood protection. Ethylbenzene is a colorless organic liquid with a sweet, gasoline-like odor. Its most common use is to make styrene, another organic liquid used as a building block for many plastics. It is also used as a solvent for coatings, and in making rubber and plastic wrap. SWIFT Green filters are NSF Gold certified by WQA to remove these contaminants and many others.

9. Can I recycle my water filter?

Yes, please send used Swift Green Filter to the following address:

Mail used Swift Green Filters to:

Swift Green Filter Recycling 2678 Ram Bay Road Manning,SC 29102

10. How tightly should I tighten the filter?

All of the filters will hit a stop when they are fully tightened. As long as you install them firmly by hand (not using tools) you will feel the filter hit the stop and know that it is properly installed. Most of the filters only require a quarter to a half turn to tighten.

11. How often do I need to change my refrigerator water filter?

You need to change your refrigerator water filter every six months, as:

- 1. It provides better tasting and smelling water
- 2. It helps remove fine particles and sediment from the water
- 3. It prevents unabsorbed water contaminants and newly formed bacteria from being reintroduced into your drinking water
- 4. Prevents a water pressure decrease from the dispenser
- 5. Drinking filtered water from your refrigerator can save you over \$600 a year over using bottled water.

12. If I use less water can I change the filter less regularly?

Current industry standards dictate that fridge filters should be changed every six months. As this is their optimum life span - once the filter has been soaked on its initial use, it should be changed 6 months thereafter. This is mainly because over a period of time carbon begins to harbor bacteria which may significantly reduce the filtration performance of the fridge filter, and potentially leech bacterial contaminants into your water.

13. What if I have a problem I can't solve or that is not addresses in the FAQ's? If you are unable to find a solution, email us <u>cs@swiftgreenfilters.com</u> or call 1-888-223-6762 X 102

14. What Warranty do you provide?

Due to the short life span of a fridge filter (typically 6 months), SWIFT Green filters are under warranty for 90 days from the date of purchase. If the filter you purchased does not fit or is determined to be defective in any way, SWIFT will either refund your money or ship an appropriate replacement.

15. Will using an after market compatible filter invalidate my fridge warranty? No, it will **NOT** invalidate your fridge warranty. Manufacturers cannot restrict the sale of consumables by threatening to withdraw warranties.

16. My water dispenser is not dispensing water, what is the cause?

1. No water flow is an indication the filter is not properly installed. Try reinstalling. Push the new filter into the receiver and firmly turn to the right. When all else fails have another person look at it. A "new set of eyes" will often solve the mystery.

2. We recommend soaking the new filter in water for 10 minutes before installing.

3. Make sure the water line to refrigerator is turned on. The saddle valve is used to connect the water supply line to the house plumbing and must be fully open for the refrigerator to receive water.

4. Remember the dispenser in the door will not operate unless the door is closed

17. What causes water to be cloudy after I installed my new fridge filter?

The cloudiness is caused by microscopic air bubbles. Simply run two to three gallons of water through and the air bubbles will clear out.

18. What causes my new filter to make a noise?

This is caused by trapped pockets of air in your new filter, run two to three gallons of water through to flush out.

19. I have little black granules in my water after installing the new filter?

This is normal and happens with ALL carbon filters. These are carbon fines (tiny pieces of carbon). Flushing two to three gallons of water through the filter will purge out any loose carbon fines.

A few drops are normal, but you can also prevent water from missing the glass and dripping down the cradle area by moving glass slower when removing it from the cradle. Dispenser drips water constantly will be a water valve problem, and should be checked by a service technician