


## 1 Description

Aube's TH115 programmable thermostat has three temperature control modes:

- A mode:** ▶ controls the ambient air temperature
- F mode:** ▶ controls the floor temperature using an external temperature sensor
- AF mode:**
  - ▶ controls the ambient air temperature
  - ▶ maintains the floor temperature within desired limits using an external temperature sensor



<sup>1</sup> Place the switch in Standby to cut power to the heater when not in use (e.g., in the summer). This will not affect the time and temperature settings.

<sup>2</sup> If your thermostat is installed on a power base equipped with a ground fault protection, to reset the ground fault protection, switch the thermostat to Standby and back to On.

<sup>3</sup> The thermostat displays the percentage of heating time required to maintain the desired temperature. For example, 40 is displayed when heating is activated 40 percent of the time.


Display	1	2	3	4	5
% of heating time	1 to 24%	25 to 49%	50 to 74%	75 to 99%	100%

<sup>4</sup> GFI appears when the ground fault protection has tripped.

## 2 Configuration

Some thermostat configurations can be modified via switches on the back of the faceplate (control module).

Default (factory) settings are inside the gray cells.



#	Configurations	UP	DN
1	Display format	°F / 12 h	°C / 24 h
2	Early Start <sup>a</sup>	Enable	Disable
3	Temperature control mode <sup>b</sup>	F	AF


a. Early Start can be used in Automatic mode only. When this function is enabled, the thermostat calculates the optimal time to start heating in order to obtain the desired temperature by the set time. The thermostat re-assesses the start time daily based on the previous day's results.

NOTE: If you wish to use only 2 periods, set periods "1 and 4" or periods "2 and 3". Early Start will not work if you set periods "1 and 2" or periods "3 and 4"

b. To select the F mode, place the switch in the F position. To select the AF mode, place the switch in the AF position and ensure that the remote temperature sensor is connected to the thermostat. To select the A mode, place the switch in the AF position and ensure that the remote temperature sensor is **NOT** connected to the thermostat.

## 3 Installation

- 1 Refer to the installation instructions of the power base.
- 2 Insert the tabs at the top of the control module in the slots at the top of the power base.
- 3 Secure the control module using the captive screw underneath the base.



**NOTE:** Keep the thermostat's air vents clean and unobstructed at all times.

## 4 Clock and Day Setting


- 1 Press the **Hour** button to set the hour.
- 2 Set the **Min** button to set the minutes.
- 3 Set the **Day** button to set the day.
- 4 Press **Mode/Ret** to exit.

### Daylight Savings Time

The thermostat can automatically re-adjust its clock at Daylight Savings Time changeover. When this function is enabled (On), the thermostat switches to Daylight Savings Time on the second Sunday of March and to normal time on the first Sunday of November.

**NOTE:** The function is disabled (default setting) when the clock loses its setting.

- 1 Press the **Day** button (3 seconds) until **DLS** appears on the screen.
- 2 Press the ▲▼ to toggle between On (enabled) and Off (disabled).
- 3 Press the **Day** button briefly. The year setting is displayed.
- 4 Press the ▲▼ to set the current year.
- 5 Press the **Day** button briefly. The month setting is displayed.
- 6 Press the ▲▼ to set the current month.
- 7 Press the **Day** button briefly. The date setting is displayed.
- 8 Press the ▲▼ to set the current date.
- 9 Press **Mode/Ret** to exit.



## 5 Backlight

The display illuminates for 12 seconds when the backlight button is pressed.

When either of the ▲▼ buttons is pressed, the display also illuminates for 12 seconds. The setpoint temperature appears for 5 seconds, then the actual (measured) temperature is displayed.

## 6 Temperature Adjustment

### 6.1 Setpoint Temperature

The thermostat normally displays the actual (measured) temperature. To view the setpoint, press one of the ▲▼ buttons once. The setpoint will appear for the next 5 seconds.

To change the setpoint, press one of the ▲▼ buttons until the desired temperature is displayed. To scroll faster, press and hold the button.

### 6.2 Preset Temperatures

The thermostat has 3 preset temperatures:

- ▶ Comfort temperature ☀
- ▶ Economy temperature ☾
- ▶ Vacation temperature ☑

To use a preset temperature, briefly press the corresponding button. The corresponding icon ☀, ☾ or ☑ will be displayed.

The following table shows the intended use and the default setting of each of the preset temperatures.

Icon	Intended use	A/AF modes	F mode
☀	Comfort (when at home)	21 °C (70 °F)	28 °C (82 °F)
☾	Economy (when asleep or away from home)	17 °C (63 °F)	20 °C (68 °F)
☑	Vacation (during prolonged absence)	10 °C (50 °F)	10 °C (50 °F)

To store a preset temperature:


- 1 Set the desired temperature using the ▲▼ buttons.
- 2 Press and hold the corresponding button until the corresponding icon is displayed.

### 6.3 Floor Temperature Limits (AF mode only)

**NOTE:** To avoid damaging your floor, follow your floor supplier's recommendations regarding floor temperature limits.

The minimum and maximum floor temperature limits are 5 °C (41 °F) and 28 °C (82 °F) by default. To modify these limits, proceed as follows:

- 1 Switch the thermostat to Standby.
- 2 Press and hold the button.
- 3 Switch the thermostat back to On.
- 4 Release the button when the minimum temperature limit (FL:LO) appears.
- 5 Set the minimum temperature limit using the buttons.
- 6 Press the button to display the maximum temperature limit (FL:HI).
- 7 Set the maximum temperature limit using the buttons.
- 8 Press **Mode/Ret** to exit.



## 7 Modes of Operation

The thermostat has 3 modes of operation.

### 7.1 Automatic Mode

The thermostat follows the programmed schedule. To place the thermostat in this mode, press **Mode/Ret** until is displayed. The data of the current schedule period are also displayed.

#### Temporary Bypass

If you modify the setpoint temperature (by pressing the , or button) when the thermostat is in automatic mode, the new temperature will be used until the beginning of the next period. flashes during the bypass. You can cancel the bypass by pressing **Mode/Ret**.

#### Programmed Schedule

The schedule consists of 4 periods per day which represents a typical week day. You can program the thermostat to skip the periods that do not apply to your situation. For example, you can skip periods 2 and 3 for the weekend.

Period	Description	Associated temperature setting
	Wake-up	
	Away from home	
	Return home	
	Sleep	

The Comfort () temperature is used in periods 1 and 3 and the Economy () temperature is used in periods 2 and 4. For example, when the period changes from 1 to 2, the setpoint automatically changes from Comfort () temperature to Economy () temperature.

You can have a different program for each day of the week; i.e., each period can start at different time for each day of the week. The thermostat has been programmed with the following schedule.

Period	Setting	MO	TU	WE	TH	FR	SA	SU
		6:00	6:00	6:00	6:00	6:00	6:00	6:00
		8:30	8:30	8:30	8:30	8:30	--:--	--:--
		17:00	17:00	17:00	17:00	17:00	--:--	--:--
		23:00	23:00	23:00	23:00	23:00	23:00	23:00

To modify the schedule:

- 1 Press **Pgm** to access the programming mode. Period 1 is selected.
- 2 Press **Day** to select the day to program (hold for 3 seconds to select the entire week).
- 3 Press **Hour** and **Min** to set the start time of the selected period, or press **Clear** if you want to skip the period (--:-- is displayed).  
**NOTE:** If you wish to use only 2 periods, set periods "1 and 4" or periods "2 and 3". Early Start will not work if you set periods "1 and 2" or periods "3 and 4".
- 4 Press **Pgm** to select another period, or press **Day** to select another day. Then repeat step 3.
- 5 Press **Mode/Ret** to exit the programming mode.

**NOTE:** If no button is pressed for 60 seconds, the thermostat will automatically exit the programming mode.

### 7.2 Manual Mode

The programmed schedule is not used. The temperature must be set manually. To place the thermostat in this mode:

- 1 Press **Mode/Ret** until is displayed.
- 2 Set the temperature using the , or button.

### 7.3 Vacation Mode

In this mode, the thermostat is set to Vacation temperature. There are two ways to place the thermostat in Vacation mode:

- ▶ By pressing the button on the thermostat. When the Vacation mode is activated using the button, the icon appears on the screen without flashing.
- ▶ From an Aube telephone controller (CT240/CT241) or any other remote control device equipped with a dry contact if your power base is equipped with the ECONO input. When the contact closes, the Vacation mode is activated and the icon flashes on the screen. All buttons on the thermostat are locked. When the contact opens, the thermostat returns to the preceding mode.

**NOTE:** When the Vacation mode is activated using a remote control device, it can only be deactivated using the device.

## 8 Error Messages

- LO The measured temperature is below the thermostat's display range. Heating is activated.
- HI The measured temperature is above the thermostat's display range. Heating is deactivated.
- Er Verify the thermostat and sensor connections.

## 9 Technical Specifications

- Power supply:** Refer to the power base's installation guide.
- Display range:** 0 °C to 70 °C (32 °F to 158 °F)
- Ambient setpoint range (A/AF modes):** 5 °C to 30 °C (40 °F - 86 °F)
- Floor setpoint range (F mode):** 5 °C to 40 °C (40 °F - 104 °F)
- Floor limit range (AF mode):** 5 °C to 40 °C (40 °F - 104 °F)
- Display resolution:** 0.5 °C (1 °F)
- Operating temperature:** 0 °C to 50 °C (32 °F to 120 °F)
- Storage temperature:** -20 °C to 50 °C (-4 °F to 120 °F)
- Heating cycle length:** Refer to the power base's installation guide
- Data backup:** In the event of a power failure, most settings are saved. Only the time must be re-adjusted if the power failure lasts more than 6 hours. The thermostat will return to the mode that was active prior to the power failure.

## Warranty

Aube warrants this product, excluding battery, to be free from defects in the workmanship or materials, under normal use and service, for a period of three (3) years from the date of purchase by the consumer. If at any time during the warranty period the product is determined to be defective or malfunctions, Aube shall repair or replace it (at Aube's option).

- If the product is defective,
- (i) return it, with a bill of sale or other dated proof of purchase, to the place from which you purchased it, or
  - (ii) contact Aube. Aube will make the determination whether the product should be returned, or whether a replacement product can be sent to you.

This warranty does not cover removal or reinstallation costs. This warranty shall not apply if it is shown by Aube that the defect or malfunction was caused by damage which occurred while the product was in the possession of a consumer.

Aube's sole responsibility shall be to repair or replace the product within the terms stated above. AUBE SHALL NOT BE LIABLE FOR ANY LOSS OR DAMAGE OF ANY KIND, INCLUDING ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING, DIRECTLY OR INDIRECTLY, FROM ANY BREACH OF ANY WARRANTY, EXPRESS OR IMPLIED, OR ANY OTHER FAILURE OF THIS PRODUCT. Some provinces, states or regions do not allow the exclusion or limitation of incidental or consequential damages, so this limitation may not apply to you. THIS WARRANTY IS THE ONLY EXPRESS WARRANTY AUBE MAKES ON THIS PRODUCT. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IS HEREBY LIMITED TO THE THREE-YEAR DURATION OF THIS WARRANTY. Some provinces, states or regions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from province, state or region to another.

## Customer Assistance

For any questions regarding product installation or operation, contact us at:

705 Montrichard  
 Saint-Jean-sur-Richelieu, Quebec  
 J2X 5K8  
 Canada  
 Tel.: (450) 358-4600  
 Toll-free: 1-800-831-AUBE  
 Fax: (450) 358-4650  
 E-mail: aube.service@honeywell.com



For more information on our products, visit us at:  
[www.aubetech.com](http://www.aubetech.com)

## 1 Applications

This power base has been designed for floor heating applications. It has ground fault protection (GFCI<sup>1</sup> or EGFPD<sup>2</sup>) and an input for connecting a floor sensor.

If your thermostat has the Vacation Mode, the mode can be activated by connecting an Aube telephone controller (CT240 or CT241) or any other remote control device equipped with a normally open (NO) dry contact. For more information on this mode, see the thermostat's user guide.

**NOTE:** This power base must be used with thermostat operating on 15-minute cycles.

<sup>1</sup> Ground Fault Circuit Interrupter

<sup>2</sup> Equipment Ground Fault Protection Device

## 2 Supplied Parts

- 1 One (1) power base
- 2 Two (2) screws
- 3 Four (4) solderless connectors for copper wires

**NOTE:** Special CO/ALR solderless connectors must be used for connecting aluminum conductors.

- 4 One (1) floor sensor
- 5 One (1) flat-tip screwdriver


## 3 Installation Guidelines

- ▶ Install the thermostat onto an electrical box.
- ▶ Do NOT install the thermostat in an area where it can be exposed to water or rain.

## 4 Installation Procedure


Installation should be carried out by an electrician and must comply with local electrical codes.

- 1 Turn off power to the heating system at the main power panel in order to avoid any risk of electrical shock.
- 2 Connect the power base wires to the power supply and to the load using solderless connectors for copper wires.



- 3 Insert the floor sensor cable through one of the two openings on the base and connect the sensor wires to terminals 1 and 2 (no polarity).

Position the sensor cable such that it does not come in contact with the floor heating wires. The sensor probe must be centered between two floor heating wires for best temperature control.




- 4 If you wish to connect a remote control device, insert the wires (use 18- to 22-gauge flexible wires) through one of the two openings on the base and connect them to terminals 2 and 3 (no polarity).
- 5 Push the excess length of the high-voltage wires back inside the electrical box.
- 6 Secure the power base to the electrical box using the provided screws.
- 7 Verify the settings of the configuration switches (if any) on the back of the control module (see user guide).
- 8 Install the control module on the base (see user guide).
- 9 Apply power to the heating system. Verify the installation by making sure that the heating system can be turned on and turned off by increasing and decreasing the setpoint.
- 10 Test the ground fault protection.

## 5 Ground Fault Protection

### 5.1 Description

The power base protects against risks of electrocution caused by leakage current. If the leakage current exceeds 5 mA or 15 mA (depending on the model), the ground fault protection will automatically trigger, cutting power to the floor heating system. To indicate the fault, the **TEST** light on the top of the base will illuminate (red).



### 5.2 Ground Fault Protection Reset

When the ground fault protection has triggered, reset it by switching the thermostat to **Standby** and back to **On**. The **TEST** light will go off.

### 5.3 Ground Fault Protection Test

To ensure the ground fault protection is always in working order, test it once the thermostat is installed and on a monthly basis thereafter.

- ❶ Increase the setpoint temperature above the measured floor temperature in order to activate the floor heating system.
- ❷ Press the **TEST** button.
  - The test is successful if the **TEST** light is On (red). Reset the thermostat and place it back to the desired temperature.
  - The test has failed if the **TEST** light remains off. Cut power to the heating system at the main electrical panel and replace the thermostat.

## 6 Technical Specifications

Model	Supply	Maximum Load		Wiring
		Current	Power	
120GA	120 VAC, 50/60Hz	15 A	1800 W	4 wires double pole
120GB	120 VAC, 50/60Hz	15 A	1800 W	4 wires double pole
240GA	240 VAC, 50/60Hz	15 A	3600 W	4 wires double pole
	208 VAC, 50/60Hz		3120 W	
240GB	240 VAC, 50/60Hz	15 A	3600 W	4 wires double pole
	208 VAC, 50/60Hz		3120 W	

Model	Ground Fault Protection	Leakage Current
120GA	Ground Fault Circuit Interrupter (GFCI)	5 mA
120GB	Equipment Ground Fault Protection Device (EGFPD)	15 mA
240GA	Ground Fault Circuit Interrupter (GFCI)	5 mA
240GB	Equipment Ground Fault Protection Device (EGFPD)	15 mA

**Heating cycle length:** 15 minutes

**Storage:** -20 °C to 50 °C (-4 °F to 120 °F)

**Size (H • W • D):** 124 x 70 x 23 mm (4.89 x 2.76 x 0.91 in.)

**Certifications:**

