

SHOWER FILTER INSTALLATION INSTRUCTIONS

WHAT'S THIS FOR?

These instructions tell you how to quickly install and start enjoying your new shower filter.

The shower filter installs quickly and easily on any standard 1/2" threaded connection (the universal size in North America and Europe). For best results, keep water temperature between 40-175°F (or 4-80°C).

TOOLS REQUIRED:

- Teflon Tape (included)
- Wrench (optional)

STEP 1: FLUSH SHOWER FILTER

Hold the shower filter under a faucet and turn the water on to flush out excess carbon particles from the filter. This may turn the water grey for the first few seconds. Keep flushing the filter for 20 seconds. Turn the shower filter over and flush the other direction.



STEP 2: REMOVE EXISTING SHOWER HEAD

Remove the existing shower head from the shower arm by turning counterclockwise. This can usually be done by hand, but you may need a wrench if your old shower head is on too tight. Use your fingers to peel away the old Teflon tape and clean the threaded pipe.



STEP 3: WRAP NEW TEFLON TAPE

Wrap the included Teflon tape tightly around the threads of your shower filter and the shower arm. 5-8 full turns around the threads is sufficient to provide coverage. (There is no need to use the small, white rubber o-rings that came with the filter. The Teflon tape alone is sufficient.)



STEP 4: TWIST ON SHOWER FILTER AND HEAD

Place the new shower filter on the shower arm and turn clockwise to tighten by hand. Then twist on your shower head and also tighten by turning clockwise. If additional tightening is needed, use a soft cloth to protect the finish and tighten with a wrench. Then enjoy!

