

G-206 REPLACEMENT EVAPORATOR PAD FOR MODEL G200 HUMIDIFIER

1. Turn off the water supply (saddle valve located on the water line) by turning the valve handle clockwise. Disconnect electrical power to the furnace.
2. Fully loosen the screw located at the bottom of the humidifier cover (It will remain attached to the cover). Remove the cover by pulling out on the bottom of the unit, then lifting up slightly.
3. Pull out the distribution tray which rests above the evaporator pad.
4. Pull the pad and frame towards you, being careful of the drain connection. Remove the old evaporator pad by pulling it out from the top. Discard the pad. Carefully remove calcium deposits from the drain tray and frame.
5. Take the plastic bag off of the new evaporator pad and insert the pad into the frame with the colored spot up.
6. Return the frame and pad to the humidifier. Install the distribution tray. Place the humidifier cover over the base and secure it by tightening the screw.
7. Remove the drain hose and clamp from the bottom of the unit. To insure against calcium deposits forming in the drain hose, bend and flex it. Flush with water, place back on the drain fitting, and secure with the clamp.
8. Turn the water on and restore power to the furnace.