

Tools Needed: phillips screwdriver



•Remove the three retaining screws at the base of the glove box assembly



2

- •Open the glove box, remove contents.
- •Remove the three retaining screws at the top of the glove box assembly



3

•After removing the screws pull on the top corners of the glove box to disengage the assembly and gently pull and remove the glove box. You will also need to twist and remove the glove box light connectors that are located at the top and rear of the backside of the glove box assembly.





**Cabin Air Filtration Product** 

## MicronAir® No. GM07113P



•Once the glove box assembly is removed you will see the filter access door. Unlock the two latches on the front of the housing access door and lift it up. The filter will now be exposed.





- 5
- •Remove the used filter by pulling straight out.
- •Replace with a clean micronAir® cabin air filter.
- •Replace the filter cover and reinstall the glove box assembly.



This micronAir Cabin Filter fits: GM Saturn VUE from model year '08 Get in and breathe easy.