



Cabin Air Filtration Product MicronAir® No. GM97167P

1

Tools
Standard screw
driver

- **Park Avenue:** Place the ignition switch in the Off position, remove the supplemental inflatable restraint fuse from the under hood fuse panel. Remove the left sound insulator fasteners. **Note the location of the left sound insulator fasteners so they can be installed at the same positions. Improper installation of the fasteners may result in brake or accelerator pedal binding. SIR system wiring and components are located in this area, use extreme caution.** Disconnect the left sound insulator electrical connectors, then remove the insulator.
- **Seville:** Place the ignition switch in the Off position, remove the supplemental inflatable restraint fuse from the rear fuse panel. **On 1997 models,** the rear fuse panel is located in the luggage compartment. **On the 1998-2003 models,** the rear fuse panel is located under the rear seat. Remove the two retaining screws from the rear edge of the left sound insulator. Push in on the snap tabs to release the insulator. Disconnect the left sound insulator electrical connectors, then remove the insulator. Twist the shift cable grommet and position away from the cabin air filter access door. It may be necessary to cut the tie strap and peel back the foam insulation to position the grommet away from the door.

2

- **Seville & Park Avenue:** Remove the cabin air filter access cover from the A/C and heater module. For Park Avenue models since 2000, pull the cabin air filter access cover down and then out to remove from the A/C and heater module.

3

- **Seville & Park Avenue:** Remove the tape, then pull out the first cabin air filter element using the filter tab. Remove the tape, then pull out the second cabin air filter element using the filter tab. Remove the tape, then pull out the third cabin air filter element using the filter tab.

4

- **Seville & Park Avenue:** To ease installation, lubricate the new filter guides with silicon spray. Install the first clean micronAir® cabin air filter into the case. Using a long thin blade screw driver and filter tab, raise the filter until it is parallel with the A/C and heater module. Ensure the leading edge of the filter engages the filter case holding rib. Engage the new second micronAir® cabin air filter in the tab of the first filter. Slide the second filter into the remaining channels of the first filter. Using the filter tab, raise the filter until it is parallel with the A/C and heater module. Ensure the leading edge of the filter engages the filter case holding rib. Engage the third new micronAir® cabin air filter in the tab of the second filter. Slide the third filter into the remaining channels of the second filter. Fold the tab of the second filter down. Fold the tab of the third filter up and over the second filter.

5

- **Seville & Park Avenue:** Install the A/C and heater module filter cover. Ensure the cover is properly seated. For Seville, position the shift cable grommet. Position the left sound insulator to the instrument panel, then connect the electrical connectors. Install the left sound insulator fasteners. Torque the fasteners to 18 inch lbs (Seville), 17 inch lbs (Park Avenue). Be sure to install the fasteners in the proper locations. Install the SIR fuse. From a position off to the side of the air bag module, place the ignition switch in the On position. The air bag warning lamp should flash 7 times and then turn Off. Place the ignition switch in the Off position.

This micronAir® Cabin Air Filter fits: Buick Park Avenue; and the Cadillac Seville, from Model Year 1997.

Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.

Engineered for Original Equipment Manufacturer Specifications.

www.micronAir.com

908549 REV. A 56