



Cabin Air Filtration Product MicronAir® No. GM99105P, GM99105C

1

Tools

- Screwdriver
- Socket wrench

- Open door to passenger side of vehicle.



2

- Under glove compartment is a kick plate cover held in place by four screws. Remove the screws and take off cover.



3

- The door to the micronAir® Cabin Air Filter is now visible. Remove screw in door and unhinge.



4

- Remove the first filter by pulling straight down.
- Remove the second filter by sliding forward and pulling down.
- Replace with clean micronAir® Cabin Air Filters.
- Reattach door.
- Reattach kick plate cover.



This micronAir® Cabin Air Filter fits: Chevrolet Silverado, Suburban, Tahoe and GMC Sierra/CK Pickup and GMC Yukon, Model Year 1999-2002; and the Cadillac Escalade, GM Avalanche and GMC Denali Model year 2001-2002.

Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.
Engineered for Original Equipment Manufacturer Specifications.