



Cabin Air Filtration Product MicronAir® No. MB91132P

1

Tools:
Phillips screw
driver

- Open hood.
- Pull up cowl seal.
- Disconnect the vacuum hoses from the main air flap actuators.
- Lift up the air plenum housing.

2

- Turn the windshield heating thermostatic valve counterclockwise to disengage.
- Lift the outside temperature sensor upward and position out of the way.
- Remove the air plenum housing.

3

- Remove the cabin filter from the filter housing.
- Install a new cabin filter, ensuring the filter is properly positioned in the housing.
- Install the air plenum housing.
- Install the outside temperature sensor.

4

- Engage the windshield heating thermostatic valve clockwise.
- Connect the vacuum hoses to the main air flap actuators.
- Install the cowl seal.
- Close the hood.

This MicronAir® Cabin Air Filter fits: Mercedes S class, model years 1991-1998.

Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.
Engineered for Original Equipment Manufacturer Specifications.