

The narrower 1" frame is converted to a 2" frame by folding and fastening the four flaps built into the frame without any tools in very little time. The following directions and figures are found on each flap and outline how the flap is folded back and the tabs are inserted back into the frame.

### **Directions**

1. Lift flap away from frame to break free from tear-off coupons.
2. Fold back flap along perforations, see Figure 1.
3. Insert tabs into slits marked on frame, see Figure 2.
4. Press tabs completely into frame until flap is flush, see Figure 3.

