

# Santa Fe Rx

## Set-Up Instructions

 **Therma-Stor**  
PO Box 8050, Madison, WI 53708  
1-800-533-7533  
[www.thermastor.com](http://www.thermastor.com)

**Before operating this unit, please read the Instruction Manual**

### How to prepare the Santa Fe Rx for operation

1. Locate the unit per the manual.
2. Cut the cable tie holding the cord and hose on top.
3. Route the hose to a drain (see manual).
4. Dehumidistat is preset at the factory. See manual for adjustment instructions.
5. Blower switch is set in the off position at the factory. See manual for blower operation options.
6. Install the filter (as shown in Figure). Air flow arrow must point down.
7. Lower the top down so the keyhole slots in the top drop over the posts. Slide the top until the catch latches to the strike (as shown in Figure).

