



## Cabin Air Filtration Product MicronAir® No. TY98163P

# 1

- **Highlander:** Remove the screw retaining the eyelet clip. Open the glove compartment door.
- **GS:** Disconnect and isolate the battery ground cable. After disconnecting the battery ground cable, wait at least 90 seconds to allow the air bag system backup power discharge. Remove the bolts attaching the glove compartment to the instrument panel. Airbag system components are located in this area, use extreme caution. Open the glove compartment door.
- **RX:** Open the glove compartment. Remove the cover from the rear of the glove compartment.

# 2

- **Highlander:** Push inward at each side of the glove compartment door to disengage the retainers, then lower the door. Through the glove compartment opening, remove the filter cover from the filter outlet. Pull the cabin filter housing from the filter outlet. Remove the cabin filter element from the filter housing.
- **GS:** Remove the three glove compartment retaining screws, then the glove compartment. Remove the filter cover, then the filter element.
- **RX:** Through the glove compartment cover opening, disengage the filter cover retainers, then remove the cover and cabin air filter housing. Remove the cabin air filter from the filter housing.

# 3

- **Highlander:** Install a new micronAir® cabin air filter element into the filter outlet. Ensure the filter element is properly positioned in the filter housing.
- **GS:** Replace with a clean micronAir® cabin air filter. Install the cabin air filter cover. Ensure the cover is securely seated. Position the glove compartment to the instrument panel, then install the attaching screws.
- **RX:** Install a new micronAir® cabin air filter into the filter housing. Through the glove compartment cover opening, install cabin air filter housing, then the filter cover. Ensure the cover is properly seated.

# 4

- **Highlander:** Install the filter housing into the filter outlet. Install the filter cover. Push inward at each side of the glove compartment door, then raise the door into place. Close the glove compartment door. Install the screw retaining the eyelet clip.
- **GS:** Close the glove compartment door, then install the two attaching bolts. Connect the battery ground cable.
- **RX:** Install the glove compartment rear cover. Close the glove compartment.

**This micronAir® Cabin Air Filter fits: Toyota Highlander, from model year 2001;  
Lexus GS, model years 1998-2000; and Lexus RX, model year 1999.**

## Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.  
Engineered for Original Equipment Manufacturer Specifications.