



## Cabin Air Filtration Product MicronAir® No. VW03179C

**1**

Tools:  
Phillips screw  
driver

- Filter is located in front passenger footwell.

**2**

- Remove footwell trim on front passenger side.

**3**

- Remove the screws on the left and right of the compartment cover.
- Remove cover.
- Filter can be removed by pulling straight down.

**4**

- Replace with a micronAir® cabin air filter.
- Replace cover and reinsert the screws.
- Replace footwell trim.

This micronAir® Cabin Air Filter fits: VW Toureg, from model year 2003.

# Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.

Engineered for Original Equipment Manufacturer Specifications.