



## Cabin Air Filtration Product MicronAir® No. VW06181P, VW06181C

**1**

- Open hood.

**2**

- Remove plenum cover.
- Release cabin air filter retaining tab catches.
- Fold the tab back.

**3**

- Remove the cabin filter.
- Install a new micronAir® cabin air filter.

**4**

- Fold the retaining clip into position and engage the catches.
- Reinstall cover.

**This MicronAir® Cabin Air Filter fits: Audi A6, model years 2005-2006.**

# Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.  
Engineered for Original Equipment Manufacturer Specifications.