



Cabin Air Filtration Product MicronAir® No. VW94157C

1

- Open hood.

2

- Locate filter housing on underside of hood.
- Press in quick lock retainer and turn 90 degrees.

3

- Remove the cabin filter by pulling it straight down. Install a new cabin filter.

4

- Replace housing, press in quick lock retainer and turn.

This MicronAir® Cabin Air Filter fits: Audi A8, from model year 1994.

Get in and breathe easy.

*The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.
Engineered for Original Equipment Manufacturer Specifications.*