



Cabin Air Filtration Product MicronAir® No. BM00148P, BM00148C

1

- Open the hood.
- Turn the cabin air filter retainer 1/4 turn.

2

- Remove the cabin air filter cover.
- Remove the cabin air filter element from the filter housing.

3

- Replace with a clean micronAir® Cabin Air Filter.

4

- Install the cabin air filter cover. Secure the cover by turning the retainer 1/4 turn.
- Close the hood.

This micronAir® Cabin Air Filter fits: BMW X5, from model year 2000.

Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.
Engineered for Original Equipment Manufacturer Specifications.