

"Fanguard" Installation Instructions

1. Install the "Fanguard" on the exhaust side of the fan. (close to the fan as possible)
2. Drill a $7/16$ " hole in the side of the pipe and below the fan. (locate within 36" of the fanguard)
3. Thread the hole with a $1/4$ " tapered pipe tap.
4. Insert the fitting into the pipe with the open end facing up. (use a little PVC cement on the threads)
5. Cut the tubing and the insulation to the desired length (be certain the tubing does not have any low places that would trap water)
6. Push each end of the tubing over the barbed fittings.
7. Install a cap or provide another means to prevent leaves or other debris from getting down the exhaust pipe.

