



Cabin Air Filtration Product MicronAir® No. FD00168P

1

Tools

- Phillips screw driver
- Standard screw driver

Stop windshield wipers in up position.

- **Thunderbird:** Open hood. Remove left and right cowl trim pieces, and wiper arm nut covers, then the nuts and wiper arms. Remove the pin type retainers attaching the cowl cover to the cowl.
- **Lincoln:** Open hood.
- **Jaguar:** Open hood. Remove windshield wiper arm nut covers. Remove windshield wiper arm retaining nuts, then remove the wiper arms using a suitable windshield wiper arm puller.

2

- **For Thunderbird, go to step 3.**
- **Lincoln:** Remove the pin type retainers attaching the passenger side cowl cover to the cowl. Detach the rubber hinge cover from rear outer corner of the passenger side cowl cover. Pull up on the passenger side cowl cover to release the lower retaining clips, then remove the cover.
- **Jaguar:** Remove the cowl grille screw covers. Remove the cowl grille screws and retainers, then remove the cowl grille.

3

- **Thunderbird & Lincoln:** Release the right hand corner of the cabin air filter, by pushing on the retaining clips. Release the left hand corner of the cabin air filter, then lift the filter from the cowl opening. Install a new micronAir® Cabin Air Filter through the passenger side cowl opening. Ensure the air flow marking is facing in the proper direction.
- **Jaguar:** Open the Cabin Filter cover, and remove filter. Install a new micronAir® Cabin Air Filter; if filter is equipped with air flow markings, ensure the marking is facing in the proper direction. Close the Cabin Filter cover.

4

- **Thunderbird:** Install cowl cover, ensuring all retainers are properly attached; install the wiper arms, secure with nuts, then install the nut covers. Replace the left and right cowl trim pieces. Close the hood.
- **Lincoln:** Install the passenger side cowl cover. Ensure all the retainers are properly attached. Close the hood.
- **Jaguar:** Install the cowl grille. Ensure all the screws and retainers are properly secured. Position windshield wiper arms to the pivots, then install the retaining nuts and close the covers. Close the hood.

This micronAir® Cabin Air Filter fits: Ford Thunderbird, from Model Year 2002; and Lincoln LS and Jaguar S-Type, Model Years 2000-2002.

Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every year or 15,000 miles.
Engineered for Original Equipment Manufacturer Specifications.