




# HOW TO INSTALL




**1. Shut off power to furnace or air handler.**  
**Remove door and remove dirty filter.**



**2. Open new filter and attach the four side support bars as shown**



**3. Slide assembled filter into cabinet**



**4. Replace door and turn on the power**