



Cabin Air Filtration Product MicronAir® No. HN97159P

1

Tools

- Standard screw driver
- Phillips screw driver

- Open glove compartment.
- Remove the stops located at each side of the glove compartment.
- Remove the two bolts securing the glove compartment to the instrument panel; remove the instrument panel right lower cover retaining screw, then the cover.



3

- Detach the wiring harness from the evaporator housing clamps.
- Remove the filter cover from the evaporator housing.
- Remove the cabin air filter and the element from the filter housing and replace with a new micronAir® cabin air filter. Ensure the filter element and filter housing arrow markings are facing in the same direction.
- Install the cabin air filter into the evaporator housing.



2

- Remove the glove compartment frame retaining screws. Remove the glove compartment frame with the knee bolster.



4

- Install the evaporator housing filter cover. Ensure the filter cover is securely seated
- Attach the wiring harness to the evaporator housing clamps.
- Position the glove compartment frame and knee bolster to the instrument panel, then install the attaching bolts.
- Install the stops at each side of the glove compartment.



This micronAir® Cabin Air Filter fits: Honda Insight, from model year 2000;
and CRV, model years 1997-2001.

Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every 2 years or 30,000 miles.
Engineered for Original Equipment Manufacturer Specifications.