micronAir[®]

Cabin Air Filtration Product MicronAir® No. HN98104P, HN98104C



Tools

- Standard screw driver
- Phillips screw driver
- Open glove compartment.
- Remove two locking tabs from either side of compartment.
- Remove three screws on left, center & right of compartment.
- Close compartment.



- Remove access panel from right side of compartment.
- Remove two screws under access panel.
- Remove access panel in center of console under radio.
- Remove screw on right side under this panel.



- Remove access panel under alove compartment.
- Remove two screws on underside of glove compartment & one screw on metal bar.
- Remove glove compartment, disconnecting light wire on left side.





- Remove remaining two screws on either side of metal bar. Remove bar.
- The access door to the filters is now visible.
- Pull up on access door to release & remove.







- Pull out first filter in housing & slide second into opening to remove.
- Replace with clean micronAir® Cabin Air Filters.
- Reverse steps to complete filter changeout.





This micronAir® Cabin Air Filter fits: Honda Accord Model Year 1998-2002, and Acura TL from Model Year 1999.

Get in and breathe easy.

The vehicle manufacturer recommends that the filter be changed every 2 years or 30,000 miles.

Engineered for Original Equipment Manufacturer Specifications.