


Instruction Manual

Air Humidifier



Please read the manual carefully before using.

Dear customer, thanks for choosing our products.

Technical Characteristics

- Voltage: 100-120V
- Frequency: 60Hz
- Power: 25W
- Capacity: 6.5L
- Application: 375 to 575 sq. ft.
- Table Top or floor standing

Recommendation


- Please first inspect for any damage and immediately report to the seller.
- Make sure that the voltage is same as the appliance rating label marked.
- The appliance should be placed on a flat, hard surface with no obstruction underneath such as carpet or towels. Also, make sure that there is at least two feet of clearance above the unit for mist discharge.
- Do not use the appliance if it is not fully assembled or parts of the appliance are missing.
- Use only distilled water to operate the humidifier. A vinegar and water combination can be used for cleaning only.
- The water temperature should be not exceed 100° F.
- The best operating environment is temperature from 60° F to 100° F and humidity less than 80% RH.
- Do not place the appliance in direct sunlight.
- Do not place the appliance in areas near computers and sensitive electronic equipment.
- Do not use the appliance in the rooms with explosive gas or while using inflammable solvents, varnish or glue.
- It is not recommended to place the appliance under air conditioners, as it may affect the level of humidity.
- Do not pull the cord to unplug the appliance.
- Do not use the damaged appliance or appliance with damaged cord/plug.
- Do not use the appliance with wet hands.

- Do not add hot water into the water tank. Only fill water through the bottom of the tank, not through the mist nozzle.
- Do not add any aromatic substance into the water (powder, liquids, oil, etc.). Only add aromatic oil to the aroma box sponge on the bottom of the unit.
- Always unplug the appliance before cleaning.
- Do not immerse the appliance in water or wash under running water, you can damage the electronic components of the appliance.
- Keep babies and children away from the appliance.
- If you are not going to use the appliance for long time, clean and dry it well with soft fabric, pack it well.

Before First Use

- Remove the appliance from the package.
- Do not leave the packing (plastic bags, polystyrene, etc.) within reach of babies and children.
- After transportation in low temperatures, leave the appliance in the room for 2 hours to acclimate before using.

Description



- Don't add anything into the water tank except clean water.
- Remove plastic insert from the remote to activate the battery.
- The digital display stays bright during setting. The display will dim a few seconds after you are finished setting. This is to avoid irritation while sleeping.

Operating

You can set the machine by the touch panel on the base or by remote control. If remote control fails to work, make sure a battery is installed and the plastic is removed to activate the battery.


- Place the appliance on the level and firm surface.
- Do not operate the unit without water.
- To fill the tank, remove the mist nozzle to access the easy carry handle.
- Remove the water tank from the base and unscrew the lid from the fill hole on the bottom of the water tank.
- Fill with distilled water and be sure to properly reinstall the lid. Make sure the tank inlet has the **silicon ring** on it to ensure no leakage.
- Before placing the water tank on the base, you can turn the base upside down to put oil on the Aroma Sponge if you desire. 2 to 3 drops of oil on the sponge are usually adequate depending on the quality of oil and desired amount of aroma. Wash the sponge and dry it well after using.
- Make sure the antimicrobial filter is properly in place and place the water tank on the base.
- Replace the mist nozzle.
- Plug in the appliance, touch the ON/OFF icon on the base or press the ON/OFF button on the remote control. The appliance will beep one time. The LCD display will be on. The display will show the humidity % in the room and the mist speed. The mist will start coming out after some seconds.
- Press the MIST icon on the base or FOGMETER on the remote control to adjust the speed from 1 to 3, weak—medium—strong.
- Press the TIMER icon on the remote control to set the time, 1, 2, 4, 8 hours.
- Press the HUMIDITY on the base or CONSTANT icon on the remote control to set the humidity %, from 45% to 90%.

Note: When the appliance is on, it shows the current humidity level. When the set humidity level is reached the appliance stops misting.

Take in account that the tolerance between the reading of your home humidity meter and the humidifier is $\pm 5-6\%$ depending on the distance between the humidity meter and the humidifier.

Instruction Manual

Air Humidifier



Please read the manual carefully before using.

- Press LIGHT on the base or NIGHT LAMP on the remote control to turn on/off the night light.
- Press the PURIFY button to set the purify function which will send negative ions into the room. Negative ions help settle particles out of the air and are purported to improve overall sense of well-being.

- If there is not enough water in the water tank, the appliance will beep and the display will show red sign blinking. The appliance will stop working after some seconds. Unplug the appliance and refill the water tank.

Note: If moisture collects around the appliance, this is not a defect. It may be an indication that the humidity level is set too high. Reduce the mist output or reduce the humidity %.

- It is normal to hear dripping sound when the mist output is at high level.
- If the unit won't be used for an extended period of time, unplug it from the wall outlet.

Cleaning

To extend the lifespan of the appliance, it is recommended to clean it at least once a week.

- Switch off and unplug the appliance.
- Wipe the base with damp soft cloth and wipe dry. Do not use abrasive cleansers, hard brushes to avoid scratches. Do not immerse the base in water or put it under running water.
- Fill the water tank about half full and add ¼ cup of vinegar. Close the water tank and then shake it well, holding it with both hands. You can use soft brush for cleaning of tank. Remove the water and rinse tank thoroughly.

Note: The water tank should be cleaned once a week.

- Use solution of ½ vinegar and ½ water to clean the ultrasonic disc. Pour the solution on disc and leave for at least half an hour. Using the soft brush to gently clean the disc. Pour out the solution and rinse with clean water several times.

Note: Be careful not to get water on the digital display, electrical components of the base and the cord. Don't immerse the base and cord into the water.

Trouble Shooting

Problem	Solution
Humidifier doesn't work at all	Make sure it is properly plugged into the wall outlet. Switch the appliance on by pressing the ON/OFF icon on the base or remote control.
There is a strange odor	Clean the water tank with vinegar/water mix. Leave the water tank open without the cover for some time.

Small mist	Clean the atomizer. If the water has been in the unit for a long time, replace it with clean water.
------------	---

Storage

Clean the humidifier according to the CLEANING procedure and dry it thoroughly.

Don't wrap the cord around the appliance.

Keep the appliance in its original packing at room temperature, away from babies and children.

Note: The manufacturer reserves the right, without prior notice, to make changes in the appliance that do not impair its technical characteristics, and are the result of improvements in its design or production technology.

Disposal

Dispose the appliance in an environmentally friendly manner. It should not be disposed with normal household waste.

Please dispose it at a recycling center for used electrical and electronic devices.

You can obtain more information from your local authorities.