



ICE THICKNESS CONTROL

Installation Instructions

FOR USE ON ALL B, J, AND Q-MODEL ICE MACHINES (EXCEPT Q-0210)

Installation of single probe ice thickness control:

- The single probe ice thickness control snaps directly into the original probe mounting bracket.
- Connect the single wire on the probe to terminal 1C on the control board.
- No wire will be attached to terminal 1D on the control board.

NOTE: J-Model control boards that have only terminal 1C (no terminal 1D on the board), must use the new single probe ice thickness control.

Manitowoc Ice, Inc.

2110 South 26 Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA

Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879

Web Site - www.manitowocice.com

8010743
Rev. 01/27/99