

Pre-assembled Filter Retrofit for Aprilaire® Space Gard® Housing

STEP 1 REMOVE FILTER ASSEMBLY

- A. Turn off blower.
- B. Remove access door to air cleaner cabinet.
- C. Slide out plastic inner housing / filter assembly.

STEP 2 REMOVE OLD MEDIA

- A. Lay the filter on a flat surface with the dirty side facing down.
- B. Pop off pleat spacers by holding firmly and pulling straight up at edges.
- C. Unclip holding brackets on the long ends that hold cardboard flaps in place.
- D. Lift cardboard flaps clear. Compress media and remove. Discard properly.

STEP 3 INSTALL THE NEW FILTER

- A. Place the new filter in the frame with the air flow arrow pointing up (in same direction as the frame).
- B. Reconnect the four corner latches.

STEP 4 REPLACE PLASTIC INNER HOUSING INTO CABINET

- A. Slide inner assembly into outer housing.
- B. Replace access door.
- C. Turn on furnace blower.

