

# **Einbauanleitung**

Innenraumfilter

## **Fitting instructions**

Cabin air filter

## **Istruzioni di montaggio**

Filtro abitacolo

## **Notice de montage**

Filtre d'habitacle

## **Instrucciones de montaje**

Filtro de habitáculo



## **Monteringsanvisning**

Kupéfilter

**micronAir®**

**1. 1994-1997**

**2. 1994-1997**





**1. 1997-2000**

**2. 1997-2000**


**Audi A6 (C4) 1994-1997**

**Audi A6 (C5) 1997-2000**


VW95121P/C/VW95122P/C



### 3. 1994-1997



### 4. 1994-1997



④ Wechselintervall alle 15.000km oder nach einem Jahr  
④ Replacement interval 15.000km/10.000miles or  
after 12 months  
① Sostituzione dopo 15.000km o dopo un anno  
⑤ Intervalle de remplacement 15.000km ou une fois par an  
⑥ Intervalo de cambio 15.000km o después de 1 año  
⑤ Bytesinterval 15.000km eller senast inom 1 år



④ Weitere Montage erfolgt in umgekehrter Reihenfolge  
④ Assembly is the reverse order of operation  
① Per il montaggio eseguire le operazioni in senso inverso  
⑤ Le remontage s'effectue dans l'ordre inverse  
⑥ Para concluir la instalación, seguir el orden inverso  
⑤ Ytterligare ihopmontering sker i omvänt ordningsföljd