

CABIN AIR FILTER REPLACEMENT

Recommended Replacement Interval: 15,000 miles under normal operating conditions.

NISSAN CUBE, JUKE, LEAF '12-'09

Installation Time: 15 min

Tools needed: Screwdriver

Location: Under glove compartment

1. Open glove box and remove screws.
2. Remove glove compartment.
3. Locate cabin air filter access door and lift the plastic tab to remove.
4. Remove the filter from the housing, making note of the air flow direction.
5. Replace old filter with new filter making sure the flow arrow is pointing in the correct direction.
6. Reassemble in reverse order.