

## Einbauanleitung

Innenraumfilter

## Fitting Instructions

Cabin air filter

## Istruzioni di montaggio

Filtro abitacolo

## Notice de montage

Filtre d'habitacle

## Instrucciones de montaje

Filtro de habitáculo


## Monteringsanvisning

Kupéfilter


BMW 5er Serie (E39) 1997-2003

## BM97130P, BM97130C


1. \_\_\_\_\_



3. \_\_\_\_\_



2. \_\_\_\_\_



- Ⓢ Wechselintervall alle 15.000km oder nach einem Jahr
- Ⓢ Replacement interval 15.000km/10.000miles or after 12 months
- Ⓢ Sostituzione dopo 15.000km o dopo un anno
- Ⓢ Intervalle de remplacement 15.000km ou une fois par an
- Ⓢ Intervalo de cambio 15.000km o después de 1 año
- Ⓢ Bytinterval 15.000km eller senast inom 1 år



- Ⓢ Weitere Montage erfolgt in umgekehrter Reihenfolge
- Ⓢ Assembly is the reverse order of operation
- Ⓢ Per il montaggio eseguire le operazioni in senso inverso
- Ⓢ Le remontage s'effectue dans l'ordre inverse
- Ⓢ Para concluir la instalación, seguir el orden inverso
- Ⓢ Ytterligare inopmontering sker i omvänd ordningsföljd

© by Freudenberg Vliesstoffe KG  
microAir® is a registered trademark of Carl Freudenberg