

JR6 Air Purifier




RedyPure



Retain owner's manual for future reference

Operating Guidelines


The following table lists the operating parameters for this product. Operating this product outside these specifications may cause system performance issues and may even lead to personal injury and void any warranty. Please contact RedyPure® for further advice and support.

Operating Parameters	
Model	RedyPure® JR6
Rated Voltage	110~240 Volts AC
Rated Power	6 Watts
AC Adaptor Output	 12VDC. Please only use the provided power adaptor.
Dimensions	6.7 x 6.7 x 10.4 Inches (170 x 170 x 265mm)
Operational weight	3.3lb (1.5kg)
Filter Element type	Composite filter elements
Filter Elements required	Twin (2) cartridge style elements

Installation guide

System Contents

Your RedyPure® JR6 Air Purifier was carefully assembled, packaged, and shipped complete with all the parts you should require.




Unsure about something? Is there a problem?
Please contact RedyPure® via our Customer Service Center below.

Customer Service: service@redypurer.com

Website: www.redypurer.com

Connecting up the System

Step 1



Before using the air purifier for the first time, open the base and remove both filters. Make sure you remove any packaging from each filter element, or the product will not function correctly. (See page 9).

Step 2



Plug the output of the power adapter into the connector on the back of the purifier
Plug the power adaptor into an electrical outlet.
The purifier should now be in standby mode

Step 3



Push the power button once to turn the air purifier on

The purifier should now be in operational mode

Operational Guide

Power Button



The indicator light will be blue and flash for about one second when the power adaptor is first connected to the purifier, indicating the standby mode. Press the on/off button once to turn on the device; the indicator light will now be a steady blue; the purifier will operate in the default sleep mode (quiet fan speed).

Operational Mode



From default mode, press the on/off button repeatedly to cycle through fan speeds:

- High – maximum air filtering mode
- Standby – off (Press and hold for 1 Second)
- Low – standard air filtering
- Sleep – quieter sleeping mode (default mode)

The indicator light is displayed accordingly.

Sleeping Mode



Sleep mode (quieter fan speed). The indicator lights are also turned off after 5 seconds when entering sleep mode. The fan continues to operate at a more silent, low rate without any indicator lights to disturb sleep. Press the on/off button once to review device mode (after 5-seconds, the system resumes sleeping mode) or continue to press on/off to cycle through other operational modes.

Filter Timer



The filter element lifespan is dependent on how many hours and which mode of operation the air purifier is used (see table below).

The system automatically monitors the fan speed and operational hours. When the filter's lifespan is exhausted (reaches 100%), the red indicator light will stay lit until you replace filters and reset the filter timer (see filter reset).

Operation Mode Fan Speed	Filter usage hours run rate	Calculations
Sleep	x 0.5	Double filter element life
Low	x 1.0	Normal filter element life
High	x 2.0	Half filter element life

Note; Total collective hours between filter change = 1000 hrs.

Filter Reset



After replacing the filters, you need to reset the filter timer as follows:

The red change filter indicator is ON.

Place system into standby, hold the on/off button down for 3 seconds to reset the filter timer. The red indicator light will now be off. Reset complete.


The red change filter indicator is OFF. Suppose you need to replace the filters before the red change filter indicator light is on (this may be due to heavy pollutions or blocked filters requiring an earlier filter change).

First, we need to force the filter timer to expire. Place the purifier into standby mode, hold the on/off button down for 3 seconds; this will force the red indicator to light, now the unit enters the force zero clearing mode of filter lifespan. Hold the on/off button down for 3 seconds till the red indicator is off within 5 seconds. Reset complete.

If not pressing any button or short pressing the on/off button within 5 seconds, the filter lifespan will not be reset.

Filter Replacement

Step 1



Press the on/off button until the indicator light is off, turn off the power adapter, and unplug the air purifier.


Invert the purifier on a soft surface (to avoid scratching the case). Rotate the base lock cover to open and lift off the base cover, remove both filters.

Step 2



Clean out any remaining dust or hair inside the purifier using a vacuum hose or dry cloth. DO NOT use water or liquids to clean the air purifier.

Step 3




Remove any packing from the new filter elements and take note of the inward and outward sides of the filter element for correct installation.



WARNING! Keep packing materials away from children's reach.

Step 4



Slot the two new filter elements into the air purifier base, ensuring the filters' outer sides are facing outwards. Replace the purifier base and rotate the lock cover to close.

Turn the purifier upright. Re-plugin the air purifier and follow the Filter life timer reset instructions (See Page 8).

How to source replacement filters

Replacement filter elements are available from the following retailers, supplied as a pair (two filter elements per pack).

RedyPure HEPA/AC Composite Filters (x2)	
Online Store	Description
www.redypurer.com	JR6 filter
www.amazon.com	JR6 filter or B08CK673W8
www.ebay.com	JR6 filter

Or contact RedyPure Customer Service for purchasing options:

Customer Service: service@redypurer.com

Website: www.redypurer.com
