



Dynameter™ Vacuum Gauge P/N 50006-1

INSTALLATION INSTRUCTIONS:

1. Select location on the vertical suction pipe where the vacuum gauge is to be mounted. Pipe surface should be clean and dry.
2. Remove end caps from both tube ends. Hold gauge upright to prevent loss of gauge fluid.


Warning: Do not ingest gauge fluid.

Caution: Gauge fluid will stain if split.

3. Remove protective backing from the foam tape on the back of the unit and firmly press into place on piping.
4. Allow fluid to settle in gauge for several minutes and then zero the gauge by sliding the tube until the tops of both columns align with the zero mark on the pressure scale.
The gauge may be fixed in this position using the mounting screw provided.
5. Drill a 3/16" hole in piping 2 inches below the top of the gauge.

Positioning the hole below the top of the gauge will prevent condensation from potentially collecting in the u-tube gauge.

6. Insert vinyl tubing into either opening in gauge tube and push firmly.
7. Install end of the tubing into drilled hole.
Apply caulking for airtight connection.
8. Fill out label using an indelible marker.
9. Remove backing and position label next to vacuum gauge ensuring the arrow is lined up with the gauge zero.



WARRANTY

Subject to any applicable consumer protection legislation, RadonAway warrants that the Dynameter Vacuum Gauge (the "Gauge") will be free from defects in materials and workmanship for a period of five (5) years from the date of manufacture (the "Warranty Term"). Outside the Continental United States and Canada the Warranty Term is one (1) year from the date of manufacture.

RadonAway will replace any Gauge which fails due to defects in materials or workmanship. The Gauge must be returned (at owner's cost) to the RadonAway factory. Proof of purchase must be supplied upon request for service under this Warranty.

This Warranty is contingent on installation of the Gauge in accordance with the instructions provided. This Warranty does not apply where any repairs or alterations have been made or attempted by others, or if the unit has been abused or misused. Warranty does not include damage in shipment unless the damage is due to the negligence of RadonAway.

RadonAway is not responsible for installation, removal or delivery costs associated with this Warranty.

EXCEPT AS STATED ABOVE, THE GAUGE IS PROVIDED WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

IN NO EVENT SHALL RADONAWAY BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF, OR RELATING TO, THE GAUGE OR THE PERFORMANCE THEREOF. RADONAWAY'S AGGREGATE LIABILITY HEREUNDER SHALL NOT IN ANY EVENT EXCEED THE AMOUNT OF THE PURCHASE PRICE OF SAID PRODUCT. THE SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY SHALL BE THE REPAIR OR REPLACEMENT OF THE PRODUCT, TO THE EXTENT THE SAME DOES NOT MEET WITH RADONAWAY'S WARRANTY AS PROVIDED ABOVE.

For service under this Warranty, contact RadonAway for a Return Material Authorization (RMA) number and shipping information. No returns can be accepted without an RMA. If factory return is required, the customer assumes all shipping cost to and from factory.

RadonAway 3 Saber Way Ward Hill, MA 01835 TEL (978) 521-3703 FAX (978) 521-3964

Record the following information for your records:

Purchase Date _____

REV. 10/97A