NOTE: In order to ensure proper performance, it is essential that the filters be installed in the correct location. Use the icon coded labels to match the filter cartridge with their corresponding filter heads.

- 1) Close the feed water valve and lift up the faucet handle. Wait approximately 10 seconds for the water pressure to depressurize.
- 2) Twist the filter cartridge 1/4 turn to the left (as viewed from the bottom) so that the ears on the cartidge are able to disengage from the head. Firmly pull the cartridge downward to remove it form the head. It may be necessary to twist the cartridge from side to side to help free it from the head.
- 3) Remove the new filter cartridge from its sanitary sealed wrapper. (Double check to see that it is the correct replacement filter cartridge by comparing the labels.)
- 4) Using tap water, lubricate the O-ring seals to make cartridge insertion easier.
- 5) Line up the cartridge ears, insert the cartridge and push it up into the head until it is fully seated. Twist the cartridge 1/4 turn to the right to lock into place. (See Figure 1)
- 6) Open the cold water supply valve and carefully check for leaks.
- 7) RO System Flush Instructions:


Prefilters - Flush at least 2 gallons of water through filter before use.

Postfilters - Flush at least 2 gallons of water through filter before use.

RO: Run product water to drain for 24 hours.

IMPORTANT NOTE:

 Replacement of filters will result in the need to sanitize the drinking water appliance and/or the storage tank. Please refer to "Sanitizing the RO System" in the section of the System Operating and Maintence Manual for further information.





3M Purification Inc.

400 Research Parkway Meriden, CT 06450, U.S.A. Tel (866) 990-9785

(203) 237-5541 Fax (203) 283-8977

www.3Mpurification.com www.waterfactorvsystems.com

Water Factory Systems is a trademark of 3M Company used under license. 3M is a trademark of 3M Company used under license. Please recycle, Printed in U.S.A.

© 2010 3M Company, All rights reserved.

INSTR6050 0210